AMERICAN NATIONAL STANDARD

ANSI/ISA-5.1-1984 (R1992) Formerly ANSI/ISA-S5.1-1984 (R1992)

Instrumentation Symbols and Identification

NOTICE OF COPYRIGHT

This is a copyrighted document and may not be copied or distributed in any form or manner without the permission of ISA. This copy of the document was made for the sole use of the person to whom ISA provided it and is subject to the restrictions stated in ISA's license to that person. It may not be provided to any other person in print, electronic, or any other form. Violations of ISA's copyright will be prosecuted to the fullest extent of the law and may result in substantial civil and criminal penalties.



ISA-The Instrumentation. Systems, and **Automation Society**

Reaffirmed 13 July 1992

ANSI/ISA-5.1-1984 (R1992), Instrumentation Symbols and Identification

ISBN 0-87664-844-8

Copyright © 1984 by the Instrument Society of America. All rights reserved. Printed in the United States of America. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), without the prior written permission of the publisher.

ISA 67 Alexander Drive P.O. Box 12277 Research Triangle Park, North Carolina 27709

Preface

This preface is included for information and is not a part of ANSI/ISA-5.1-1984 (R1992).

This standard has been prepared as part of the service of ISA toward a goal of uniformity in the field of instrumentation. To be of real value, this document should not be static, but should be subject to periodic review. Toward this end, the Society welcomes all comments and criticisms, and asks that they be addressed to the Secretary, Standards and Practices Board, ISA, 67 Alexander Drive, P.O. Box 12277, Research Triangle Park, NC 27709, Telephone (919) 549-8411, e-mail: standards@isa.org.

The ISA Standards and Practices Department is aware of the growing need for attention to the metric system of units in general, and the International System of Units (SI) in particular, in the preparation of instrumentation standards. The Department is further aware of the benefits to U.S.A. users of ISA standards of incorporating suitable references to the SI (and the metric system) in their business and professional dealings with other countries. Toward this end, this Department will endeavor to introduce SI-acceptable metric units in all new and revised standards to the greatest extent possible. *The Metric Practice Guide*, which has been published by the Institute of Electrical and Electronics Engineers as ANSI/IEEE Std. 268-1982, and future revisions will be the reference guide for definitions, symbols, abbreviations, and conversion factors.

It is the policy of ISA to encourage and welcome the participation of all concerned individuals and interests in the development of ISA standards. Participation in the ISA standards-making process by an individual in no way constitutes endorsement by the employer of that individual, of ISA, or of any of the standards that ISA develops.

The information contained in the preface, footnotes, and appendices is included for information only and is not a part of the standard.

The instrumentation symbolism and identification techniques described in the standard accommodate the advances in technology and reflect the collective industrial experience gained since the publication of Recommended Practice RP5.1 in 1949.

This revision attempts to strengthen the standard in its role as a tool of communication in the process industries. Communication presupposes a common language; or, at the very least, it is facilitated by one. The standard offers the foundation for that common language.

When integrated into a system, the symbols and designations presented here form a concise, dedicated language which communicates concepts, facts, intent, instructions, and knowledge about measurement and control systems in the process industries.

This document is a consensus standard rather than a mandatory one. As such, it has many of the strengths and the weaknesses of consensus standards. Its primary strength is that it can be used in widespread, interdisciplinary ways. Its weakness is generally that of not being specific enough to satisfy the special requirements of particular interest groups.

The symbols and identification contained in ISA-5.1 have evolved by the consensus method and are intended for wide application throughout the process industries. The symbols and designations are used as conceptualizing aids, as design tools, as teaching devices, and as a concise and specific means of communication on all types and kinds of technical, engineering, procurement, construction, and maintenance documents.

In the past, the standard has been flexible enough to serve all of the uses just described. In the future, it must continue to do so. To this end, this revision offers symbols, identification, and definitions for concepts that were not previously described; for example, shared display/control, distributed control, and programmable control. Definitions were broadened to accommodate the fact that, although similar functions are being performed by the new control systems, these functions are frequently not related to a uniquely identifiable instrument; yet they still must be conceptualized and identified. The excellent SAMA (Scientific Apparatus Makers Association) method of functional diagramming was used to describe function blocks and function designators. To help the batch processing industries, where binary (on-off) symbolism is extremely useful, new binary line symbols were introduced and first-letter Y was selected to represent an initiating variable which could be categorized as an event, presence, or state. In general, breadth of application as opposed to narrowness has been emphasized.

The ISA Standards Committee on Instrumentation Symbols and Identification operates within the ISA Standards and Practices Department, with William Calder III as vice president. The persons listed below served as members of or advisors to the SP5.1 committee. The SP5.1 committee is deeply appreciative of the work of previous SP5.1 committees and has tried to treat their work with the respect it deserves. In addition, this committee would like to acknowledge the work of the SP5.3 committee in developing ISA-5.3, "Graphic Symbols for Distributed Control/Shared Display Instrumentation, Logic and Computer Systems." The key elements of ISA-5.3 have been incorporated into ISA-5.1, and it is the Society's intent to withdraw ISA-5.3 after publication of this revision of ISA-5.1.

The following people served as members of ISA Committee SP5.1, which prepared this standard:

NAME

R. Mulley, Chairman E. J. Blahut P. R. Boubel J. P. Carew N. Dogra J. E. Dovle C. R. Gross T. E. Hamler F. Horn A. A. Iverson A. Langelier W. E. Mapes T. C. McAvinew W. L. Mostia G. K. Pace G. Platt*, Past Chairman A. W. Reeve S. Sankaran R. M. Shah D. G. Turnbull R. von Brecht G. Wilbanks

*Member Emeritus

COMPANY

Fluor Engineers, Inc. Blahut Engineering, Inc. TXE, Inc. Stone and Webster Engineering Corporation **ANK Engineers Tweedcrest Limited** EXXON Company U.S.A. **Owens Corning Fiberglass Corporation** Allied Chemical Company ARCO Chemical Company Polaroid Corporation Eastman Kodak Company Vertech Treatment Systems AMOCO Chemicals Phelps Dodge Corporation **Bechtel Power Corporation** AWR Controls (Canada) Ltd. McDermott Engineering **Olin Chemicals Corporation** Sandwell and Company, Limited The M. W. Kellogg Company The Rust Engineering Company

The following people served as members of ISA Committee SP5:

NAME

COMPANY

Stearns Catalytic Corporation
Bailey Controls Company
Standard Oil Company of Ohio
El Paso Natural Gas Company
Fluor Engineers, Inc.
The Foxboro Company

This standard was approved for publication by the ISA Standards and Practices Board in September 1984.

NAME

COMPANY

W. Calder III, Chairman	The Foxboro Company
P. V. Bhat	Monsanto Company
N. L. Conger	Conoco
B. Feikle	Bailey Controls Company
H. S. Hopkins	Westinghouse Electric Company
J. L. Howard	Boeing Aerospace Company
R. T. Jones	Philadelphia Electric Company
R. Keller	The Boeing Company
O. P. Lovett, Jr.	ISIS Corporation
E. C. Magison	Honeywell, Inc.
A. P. McCauley	Chagrin Valley Controls, Inc.
J. W. Mock	Bechtel Corporation
E. M. Nesvig	ERDCO Engineering Corporation
R. Prescott	Moore Products Company
D. E. Rapley	Stearns Catalytic Corporation
W. C. Weidman	Gilbert Commonwealth, Inc.
K. A. Whitman	Consultant
P. Bliss*	Consultant
B. A. Christensen*	Contintental Oil Company
L. N. Combs*	Retired
R. L. Galley*	Consultant
T. J. Harrison*	IBM Corporation
R. G. Marvin*	Roy G. Marvin Company
W. B. Miller*	Moore Products Company
G. Platt*	Bechtel Power Corporation
J. R. Williams*	Stearns Catalytic Corporation
	· ·

*Director Emeritus

Contents

Sect	tion	Title	Section Number
1	Purpos	se	9
2	Scope		
	2.1	General	9
	2.2	Application to industries	9
	2.3	Application to work activities	9
	2.4	Application to classes of instrumentation and to instrument fun-	ctions 10
	2.5	Extent of functional identification	10
	2.6	Extent of loop identification	10
3	Definit	ions	
4	Outline	e of the identification system	
	4.1	General	13
	4.2	Functional identification	
	4.3	Loop identification	15
	4.4	Symbols	
5	Tables		17
6	Drawir	ngs	27
	6.1	Cautionary notes	
	6.2	Instrument line symbols	
	6.3	General instrument or function symbols	
	6.4	Control valve body symbols, damper symbols	
	6.5	Actuator symbols	
	6.6	Symbols for self-actuated regulators, valves, and other devices	s 34
	6.7	Symbols for actuator action in event of actuator power failure.	
	6.8	Primary element symbols	
	6.9	Examples — functions	
	6.10	Examples — miscellaneous combinations	
	6.11	Example — complex combinations	61
	6.12	Example — degree of detail	

1 Purpose

The purpose of this standard is to establish a uniform means of designating instruments and instrumentation systems used for measurement and control. To this end, a designation system that includes symbols and an identification code is presented.

2 Scope

2.1 General

2.1.1 The procedural needs of various users are different. The standard recognizes these needs, when they are consistent with the objectives of the standard, by providing alternative symbolism methods. A number of examples are provided for adding information or simplifying the symbolism, as desired.

2.1.2 Process equipment symbols are not part of this standard, but are included only to illustrate applications of instrumentation symbols.

2.2 Application to industries

2.2.1 The standard is suitable for use in the chemical, petroleum, power generation, air conditioning, metal refining, and numerous other, process industries.

2.2.2 Certain fields, such as astronomy, navigation, and medicine, use very specialized instruments that are different from the conventional industrial process instruments. No specific effort was made to have the standard meet the requirements of those fields. However, it is expected that the standard will be flexible enough to meet many of the needs of special fields.

2.3 Application to work activities

2.3.1 The standard is suitable for use whenever any reference to an instrument or to a control system function is required for the purposes of symbolization and identification. Such references may be required for the following uses, as well as others:

- Design sketches
- Teaching examples
- Technical papers, literature, and discussions
- Instrumentation system diagrams, loop diagrams, logic diagrams
- Functional descriptions
- Flow diagrams: Process, Mechanical, Engineering, Systems, Piping (Process) and Instrumentation
- Construction drawings
- · Specifications, purchase orders, manifests, and other lists

- · Identification (tagging) of instruments and control functions
- · Installation, operating and maintenance instructions, drawings, and records

2.3.2 The standard is intended to provide sufficient information to enable anyone reviewing any document depicting process measurement and control (who has a reasonable amount of process knowledge) to understand the means of measurement and control of the process. The detailed knowledge of a specialist in instrumentation is not a prerequisite to this understanding.

2.4 Application to classes of instrumentation and to instrument functions

The symbolism and identification methods provided in this standard are applicable to all classes of process measurement and control instrumentation. They can be used not only to describe discrete instruments and their functions, but also to describe the analogous functions of systems which are variously termed "shared display," "shared control," "distributed control," and "computer control."

2.5 Extent of functional identification

The standard provides for the identification and symbolization of the key functions of an instrument. Additional details of the instrument are better described in a suitable specification, data sheet, or other document intended for those requiring such details.

2.6 Extent of loop identification

The standard covers the identification of an instrument and all other instruments or control functions associated with it in a loop. The user is free to apply additional identification — by serial number, unit number, area number, plant number, or by other means.

3 Definitions

For the purpose of understanding this standard, the following definitions apply. For a more complete treatment, see ISA-51.1 and the ISA-75 series of standards. Terms italicized in a definition are also defined in this section.

Accessible: A term applied to a device or *function* that can be used or be seen by an operator for the purpose of performing control actions, *e.g., set point* changes, auto-manual transfer, or on-off actions.

Alarm: A device or *function* that signals the existence of an abnormal condition by means of an audible or visible discrete change, or both, intended to attract attention.

It is not recommended that the term *alarm switch* or *alarm* be used to designate a device whose operation is simply to close or open a circuit that may or may not be used for normal or abnormal interlock, start-up, shutdown, actuation of a *pilot light* or an *alarm* device, or the like. The first device is properly designated as a level *switch*, a flow *switch*, *etc.*, because "switching" is what the device does. The device may be designated as an *alarm* only if the device itself contains the *alarm function*. [See also Table 1, note (13).]

Assignable: A term applied to a feature permitting the channeling (or directing) of a signal from one device to another without the need for switching, patching, or changes in wiring.

Auto-manual station: Synonym for control station.

Balloon: Synonym for bubble.

Behind the panel: A term applied to a location that is within an area that contains (1) the *instrument panel*, (2) its associated rack-mounted hardware, or (3) is enclosed within the *panel*. Behind the panel devices are not accessible for the operator's normal use, and are not designated as *local* or front-of-*panel-mounted*. In a very broad sense, "behind the panel" is equivalent to "not normally accessible to the operator."

Binary: A term applied to a signal or device that has only two discrete positions or states. When used in its simplest form, as in "*binary* signal" (as opposed to "analog signal"), the term denotes an "on-off" or "high-low" state, *i.e.*, one which does not represent continuously varying quantities.

Board: Synonym for panel.

Bubble: The circular symbol used to denote and identify the purpose of an *instrument* or *function*. It may contain a tag number. Synonym for *balloon*.

Computing device: A device or *function* that performs one or more calculations or logic operations, or both, and transmits one or more resultant output signals. A *computing device* is sometimes called a computing *relay*.

Configurable: A term applied to a device or system whose functional characteristics can be selected or rearranged through programming or other methods. The concept excludes rewiring as a means of altering the configuration.

Controller: A device having an output that varies to regulate a controlled variable in a specified manner. A *controller* may be a self-contained analog or *digital instrument*, or it may be the equivalent of such an *instrument* in a shared-control system.

An automatic *controller* varies its output automatically in response to a direct or indirect input of a measured *process variable*. A manual *controller* is a *manual loading station*, and its output is not dependent on a measured *process variable* but can be varied only by manual adjustment.

A controller may be integral with other functional elements of a control loop.

Control station: A manual loading station that also provides switching between manual and automatic control modes of a control *loop*. It is also known as an *auto-manual station*. In addition, the operator interface of a *distributed control system* may be regarded as a *control station*.

Control valve: A device, other than a common, hand-actuated ON-OFF valve or self-actuated check valve, that directly manipulates the flow of one or more fluid process streams.

It is expected that use of the designation "hand *control valve*" will be limited to hand-actuated valves that (1) are used for process throttling, or (2) require *identification* as an *instrument*.

Converter: A device that receives information in one form of an instrument signal and transmits an output signal in another form.

An *instrument* which changes a sensor's output to a standard signal is properly designated as a *transmitter*, not a *converter*. Typically, a temperature element *(TE)* may connect to a *transmitter (TT)*, not to a *converter (TY)*.

A *converter* is also referred to as a *transducer*, however, "*transducer*" is a completely general term, and its use specifically for signal conversion is not recommended.

Digital: A term applied to a signal or device that uses *binary* digits to represent continuous values or discrete states.

Distributed control system: A system which, while being functionally integrated, consists of subsystems which may be physically separate and remotely located from one another.

Final control element: The device that directly controls the value of the manipulated variable of a control *loop*. Often the *final control element* is a *control valve*.

Function: The purpose of, or an action performed by, a device.

Identification: The sequence of letters or digits, or both, used to designate an individual *instrument* or *loop*.

Instrument: A device used directly or indirectly to measure and/or control a variable. The term includes *primary elements, final control elements, computing devices,* and electrical devices such as annunciators, *switches,* and pushbuttons. The term does not apply to parts (e.g., a receiver bellows or a resistor) that are internal components of an *instrument.*

Instrumentation: A collection of *instruments* or their application for the purpose of observation, *measurement*, control, or any combination of these.

Local: The location of an *instrument* that is neither in nor on a *panel* or console, nor is it mounted in a control room. *Local instruments* are commonly in the vicinity of a *primary element* or a *final control element*. The word "field" is often used synonymously with *local*.

Local panel: A panel that is not a central or main panel. Local panels are commonly in the vicinity of plant subsystems or sub-areas. The term "local panel instrument" should not be confused with "local instrument."

Loop: A combination of two or more *instruments* or control *functions* arranged so that signals pass from one to another for the purpose of *measurement* and/or control of a *process variable*.

Manual loading station: A device or *function* having a manually adjustable output that is used to actuate one or more remote devices. The station does not provide switching between manual and automatic control modes of a control *loop* (*see controller* and *control station*). The station may have integral indicators, lights, or other features. It is also known as a manual station or a manual loader.

Measurement: The determination of the existence or the magnitude of a variable.

Monitor: A general term for an *instrument* or *instrument* system used to measure or sense the status or magnitude of one or more variables for the purpose of deriving useful information. The term *monitor* is very unspecific — sometimes meaning analyzer, indicator, or *alarm. Monitor* can also be used as a verb.

Monitor light: Synonym for pilot light.

Panel: A structure that has a group of *instruments* mounted on it, houses the operator-process interface, and is chosen to have a unique designation. The *panel* may consist of one or more sections, cubicles, consoles, or desks. Synonym for *board*.

Panel-mounted: A term applied to an *instrument* that is mounted on a *panel* or console and is *accessible* for an operator's normal use. A *function* that is normally *accessible* to an operator in a *shared-display* system is the equivalent of a discrete *panel-mounted* device.

Pilot light: A light that indicates which of a number of normal conditions of a system or device exists. It is unlike an *alarm* light, which indicates an abnormal condition. The *pilot light* is also known as a *monitor light*.

Primary element: Synonym for sensor.

Process: Any operation or sequence of operations involving a change of energy, state, composition, dimension, or other properties that may be defined with respect to a datum.

Process variable: Any variable property of a *process*. The term *process variable* is used in this standard to apply to all variables other than *instrument* signals.

Program: A repeatable sequence of actions that defines the status of outputs as a fixed relationship to a set of inputs.

Programmable logic controller: A *controller*, usually with multiple inputs and outputs, that contains an alterable *program*.

Relay: A device whose *function* is to pass on information in an unchanged form or in some modified form. *Relay* is often used to mean *computing device*. The latter term is preferred.

The term *"relay"* also is applied specifically to an electric, pneumatic, or hydraulic *switch* that is actuated by a signal. The term also is applied to *functions* performed by a *relay*.

Scan: To sample, in a predetermined manner, each of a number of variables intermittently. The *function* of a scanning device is often to ascertain the state or value of a variable. The device may be associated with other *functions* such as recording and alarming.

Sensor: That part of a *loop* or *instrument* that first senses the value of a process variable, and that assumes a corresponding, predetermined, and intelligible state or output. The *sensor* may be separate from or integral with another functional element of a *loop*. The *sensor* is also known as a detector or *primary element*.

Set point: An input variable that sets the desired value of the controlled variable. The *set point* may be manually set, automatically set, or programmed. Its value is expressed in the same units as the controlled variable.

Shared controller: A controller, containing preprogrammed algorithms that are usually *accessible, configurable, and assignable*. It permits a number of *process variables* to be controlled by a single device.

Shared display: The operator interface device (usually a video screen) used to display *process* control information from a number of sources at the command of the operator.

Switch: A device that connects, disconnects, selects, or transfers one or more circuits and is not designated as a *controller*, a *relay*, or a *control valve*. As a verb, the term is also applied to the *functions* performed by *switches*.

Test point: A process connection to which no *instrument* is permanently connected, but which is intended for the temporary or intermittent connection of an *instrument*.

Transducer: A general term for a device that receives information in the form of one or more physical quantities, modifies the information and/or its form, if required, and produces a resultant output signal. Depending on the application, the *transducer* can be a *primary element, transmitter, relay, converter* or other device. Because the term *"transducer"* is not specific, its use for specific applications is not recommended.

Transmitter: A device that senses a *process variable* through the medium of a sensor and has an output whose steady-state value varies only as a predetermined *function* of the *process variable*. The *sensor* may or may not be integral with the *transmitter*.

4 Outline of the identification system

4.1 General

4.1.1 Each instrument or function to be identified is designated by an alphanumeric code or tag number as shown in Figure 1. The loop identification part of the tag number generally is common

to all instruments or functions of the loop. A suffix or prefix may be added to complete the identification. Typical identification is shown in Figure 1.

	TYPICAL TAG NUMBER
TIC 103	- Instrument Identification or Tag Number
T 103	- Loop Identification
103	- Loop Number
TIC	- Functional Identification
т	- First-letter
IC	- Succeeding-Letters
	EXPANDED TAG NUMBER
10-PAH-5A	- Tag Number
10	- Optional Prefix
A	- Optional Suffix
Note: Hyphens are	optional as separators

Figure 1 — Tag numbers

4.1.2 The instrument loop number may include coded information, such as plant area designation. It is also possible to set aside specific series of numbers to designate special functions; for instance, the series 900 to 999 could be used for loops whose primary function is safety-related.

4.1.3 Each instrument may be represented on diagrams by a symbol. The symbol may be accompanied by a tag number.

4.2 Functional identification

4.2.1 The functional identification of an instrument or its functional equivalent consists of letters from Table 1 and includes one first-letter (designating the measured or initiating variable) and one or more succeeding-letters (identifying the functions performed).

4.2.2 The functional identification of an instrument is made according to the function and not according to the construction. Thus, a differential-pressure recorder used for flow measurement is identified by FR; a pressure indicator and a pressure-actuated switch connected to the output of a pneumatic level transmitter are identified by LI and LS, respectively.

4.2.3 In an instrument loop, the first-letter of the functional identification is selected according to the measured or initiating variable, and not according to the manipulated variable. Thus, a control valve varying flow according to the dictates of a level controller is an *LV*, not an *FV*.

4.2.4 The succeeding-letters of the functional identification designate one or more readout or passive functions and/or output functions. A modifying-letter may be used, if required, in addition to one or more other succeeding-letters. Modifying-letters may modify either a first-letter or succeeding-letters, as applicable. Thus, *TDAL* contains two modifiers. The letter *D* changes the measured variable *T* into a new variable, "differential temperature." The letter *L* restricts the readout function *A*, alarm, to represent a low alarm only.

4.2.5 The sequence of identification letters begins with a first-letter selected according to Table 1. Readout or passive functional letters follow in any order, and output functional letters follow these in any sequence, except that output letter C (control) precedes output letter V (valve), *e.g.*, *PCV*, a self-actuated control valve. However, modifying-letters, if used, are interposed so that they are placed immediately following the letters they modify.

4.2.6 A multiple function device may be symbolized on a diagram by as many bubbles as there are measured variables, outputs, and/or functions. Thus, a temperature controller with a switch may be identified by two tangent bubbles — one inscribed *TIC-3* and one inscribed *TSH-3*. The instrument would be designated *TIC/TSH-3* for all uses in writing or reference. If desired, however, the abbreviation *TIC-3* may serve for general identification or for purchasing, while *TSH-3* may be used for electric circuit diagrams.

4.2.7 The number of functional letters grouped for one instrument should be kept to a minimum according to the judgment of the user. The total number of letters within one group should not exceed four. The number within a group may be kept to a minimum by:

- Arranging the functional letters into subgroups. This practice is described in Section 4.2.6 for instruments having more than one measured variable or input, but it may also be used for other instruments.
- 2) Omitting the *I* (indicate) if an instrument both indicates and records the same measured variable.
- **4.2.8** All letters of the functional identification are uppercase.

4.3 Loop identification

4.3.1 The loop identification consists of a first-letter and a number. Each instrument within a loop has assigned to it the same loop number and, in the case of parallel numbering, the same first-letter. Each instrument loop has a unique loop identification. An instrument common to two or more loops should carry the identification of the loop which is considered predominant.

4.3.2 Loop numbering may be parallel or serial. Parallel numbering involves starting a numerical sequence for each new first-letter, *e.g., TIC-100, FRC-100, LIC-100, AI-100, etc.* Serial numbering involves using a single sequence of numbers for a project or for large sections of a project, regardless of the first-letter of the loop identification, *e.g., TIC-100, FRC-101, LIC-102, AI-103, etc.* A loop numbering sequence may begin with 1 or any other convenient number, such as *001, 301* or *1201.* The number may incorporate coded information; however, simplicity is recommended.

4.3.3 If a given loop has more than one instrument with the same functional identification, a suffix may be appended to the loop number, *e.g., FV-2A, FV-2B, FV-2C, etc.*, or *TE-25-1, TE-25-2, etc.* However, it may be more convenient or logical in a given instance to designate a pair of flow transmitters, for example, as *FT-2* and *FT-3* instead of *FT-2A* and *FT-2B*. The suffixes may be applied according to the following guidelines:

- 1) An uppercase suffix letter should be used, *i.e.*, *A*, *B*, *C*, *etc*.
- 2) For an instrument such as a multipoint temperature recorder that prints numbers for point identification, the primary elements may be numbered *TE-25-1*, *TE-25-2*, *TE-25-3*, *etc.*, corresponding to the point identification number.
- 3) Further subdivisions of a loop may be designated by serially alternating suffix letters and numbers. (*See* Section 6.9R(3).)

4.3.4 An instrument that performs two or more functions may be designated by all of its functions. For example, a flow recorder FR-2 with a pressure pen PR-4 may be designated FR-2/PR-4. A two-pen pressure recorder may be PR-7/8, and a common annunciator window for high and low temperature alarms may be TAHL-21. Note that the slash is not necessary when distinctly separate devices are not present.

4.3.5 Instrument accessories such as purge meters, air sets, and seal pots that are not explicitly shown on a diagram but that need a designation for other purposes should be tagged individually

according to their functions and should use the same loop identification as the instrument they directly serve. Application of such a designation does not imply that the accessory must be shown on the diagram. Alternatively, the accessories may use the identical tag number as that of their associated instrument, but with clarifying words added. Thus an orifice flange union associated with orifice plate *FE-7* should be tagged *FX-7*, but may be designated *FE-7 FLANGES*. A purge meter associated with pressure gauge *PI-8* may be tagged *PI-8 PURGE*. A thermowell used with thermometer *TI-9* should be tagged *TW-9*, but may be tagged *TI-9 THERMOWELL*.

The rules for loop identification need not be applied to instruments and accessories that are purchased in bulk quantities if it is the user's practice to identify these items by other means.

4.4 Symbols

4.4.1 The examples in this standard illustrate the symbols that are intended to depict instrumentation on diagrams and drawings. Methods of symbolization and identification are demonstrated. The examples show identification that is typical for the pictured instrument or functional interrelationships. The symbols indicating the various instruments or functions have been applied in typical ways in the illustrations. This usage does not imply, however, that the applications or designations of the instruments or functions are restricted in any way. No inference should be drawn that the choice of any of the schemes for illustration constitutes a recommendation for the illustrated methods of measurement or control. Where alternative symbols are shown without a statement of preference, the relative sequence of symbols does not imply a preference.

4.4.2 The bubble may be used to tag distinctive symbols, such as those for control valves, when such tagging is desired. In such instances, the line connecting the bubble to the instrument symbol is drawn close to, but not touching, the symbol. In other instances, the bubble serves to represent the instrument proper.

4.4.3 A distinctive symbol whose relationship to the remainder of the loop is easily apparent from a diagram need not be individually tagged on the diagram. For example, an orifice flange or a control valve that is part of a larger system need not be shown with a tag number on a diagram. Also, where there is a primary element connected to another instrument on a diagram, use of a symbol to represent the primary element on the diagram is optional.

4.4.4 A brief explanatory notation may be added adjacent to a symbol or line to clarify the function of an item. For instance, the notations 3-9 psig and 9-15 psig adjacent to the signal lines to two valves operating in split range, taken together with the symbols for the failure modes, allow complete understanding of the intent. Similarly, when two valves are operated in a diverting or mixing mode from a common signal, the notations 3-15 psig and 15-3 psig, together with the failure modes, allow understanding of the function.

4.4.5 The sizes of the tagging bubbles and the miscellaneous symbols shown in the examples are the sizes generally recommended; however, the optimum sizes may vary depending on whether or not the finished diagram is to be reduced in size and depending on the number of characters that are expected in the instrument tagging designation. The sizes of the other symbols may be selected as appropriate to accompany the symbols of other equipment on a diagram.

4.4.6 Aside from the general drafting requirements for neatness and legibility, symbols may be drawn with any orientation. Likewise, signal lines may be drawn on a diagram entering or leaving the appropriate part of a symbol at any angle. However, the function block designators of Table 3 and the tag numbers should always be drawn with a horizontal orientation. Directional arrowheads should be added to signal lines when needed to clarify the direction of flow of information. The judicious use of such arrowheads, especially on complex drawings, will often facilitate understanding of the system.

4.4.7 The electrical, pneumatic, or other power supply to an instrument is not expected to be shown unless it is essential to an understanding of the operation of the instrument or the loop.

4.4.8 In general, one signal line will suffice to represent the interconnections between two instruments on flow diagrams even though they may be connected physically by more than one line.

4.4.9 The sequence in which the instruments or functions of a loop are connected on a diagram should reflect the functional logic or information flow, although this arrangement will not necessarily correspond to the signal connection sequence. Thus, an electronic loop using analog voltage signals requires parallel wiring, while a loop using analog current signals requires series interconnections. However, the diagram in both instances should be drawn as though all the wiring were parallel, to show the functional interrelationships clearly while keeping the presentation independent of the type of instrumentation finally installed. The correct interconnections are expected to be shown on a suitable diagram.

4.4.10 The degree of detail to be applied to each document or sketch is entirely at the discretion of the user of the standard. The symbols and designations in this standard can depict both hardware and function. Sketches and technical papers will usually contain highly simplified symbolism and identification. Process flow diagrams will usually be less detailed than engineering flow diagrams. Engineering flow diagrams may show all in-line components, but may differ from user to user in the amount of off-line detail shown. In any case, consistency should be established for each application. The terms *simplified, conceptual,* and *detailed* as applied to the diagrams of 6.12 were chosen to represent a cross section of typical usage. Each user must establish the degree of detail that fulfills the purposes of the specific document or sketch being generated.

4.4.11 It is common practice for engineering flow diagrams to omit the symbols of interlockhardware components that are actually necessary for a working system, particularly when symbolizing electric interlock systems. For example, a level switch may be shown as tripping a pump, or separate flow and pressure switches may be shown as actuating a solenoid valve or other interlock devices. In both instances, auxiliary electrical relays and other components may be considered details to be shown elsewhere. By the same token, a current transformer sometimes will be omitted and its receiver shown connected directly to the process — in this case the electric motor.

4.4.12 Because the distinctions between shared display/shared control and computer functions are sometimes blurred, in choosing symbols to represent them the user must rely on manufacturers' definitions, usage in a particular industry, and personal judgment.

5 Tables

The purpose of Section 5, Tables, is to define certain of the building blocks of the identification and symbolic representation system used in this standard in a concise, easily-referenced manner.

Table 1, Identification Letters, together with the Notes for Table 1, define and explain the individual letter designators used as functional identifiers in accordance with the rules of Section 4.2, Functional Identification.

Table 2, Typical Letter Combinations, attempts to facilitate the task of choosing acceptable combinations of identifying letters.

Table 3, Function Blocks - Function Designations, is an adaptation of the SAMA (Scientific Apparatus Manufacturers Association) method of functional diagramming. Two basic uses are found for these symbols: as stand-alone function blocks on conceptual diagrams, or as flags which designate functions performed by bubbles on more detailed drawings. A third use is a combination of the first two and is found in shared control systems where, for instance, the measured variable signal line enters a square root function block that is drawn adjacent to a shared controller.

Two omissions will be noted: The SAMA symbol for *Transfer* and that for an *Analog Signal Generator*. Since the ultimate use of ISA-5.1 symbolism usually requires identification to be associated with a symbol, it is advisable to use the *HIC* (manual loader) bubble for an analog signal generator and an *HS* (hand switch) with or without a relay bubble for a transfer function.

5.1 Notes for Table 1

- A "user's choice" letter is intended to cover unlisted meanings that will be used repetitively in a particular project. If used, the letter may have one meaning as a firstletter and another meaning as a succeeding-letter. The meanings need to be defined only once in a legend, or other place, for that project. For example, the letter *N* may be defined as "modulus of elasticity" as a first-letter and "oscilloscope" as a succeeding-letter.
- 2) The unclassified letter X is intended to cover unlisted meanings that will be used only once or used to a limited extent. If used, the letter may have any number of meanings as a first-letter and any number of meanings as a succeeding-letter. Except for its use with distinctive symbols, it is expected that the meanings will be defined outside a tagging bubble on a flow diagram. For example, *XR-2* may be a stress recorder and *XX-4* may be a stress oscilloscope.
- 3) The grammatical form of the succeeding-letter meanings may be modified as required. For example, "indicate" may be applied as "indicator" or "indicating," "transmit" as "transmitter" or "transmitting," *etc*.
- 4) Any first-letter, if used in combination with modifying letters *D* (differential), *F* (ratio), *M* (momentary), *K* (time rate of change), *Q* (integrate or totalize), or any combination of these is intended to represent a new and separate measured variable, and the combination is treated as a first-letter entity. Thus, instruments *TDI* and *TI* indicate two different variables, namely, differential-temperature and temperature. Modifying letters are used when applicable.
- 5) First-letter *A* (analysis) covers all analyses not described by a "user's choice" letter. It is expected that the type of analysis will be defined outside a tagging bubble.
- 6) Use of first-letter *U* for "multivariable" in lieu of a combination of first-letters is optional. It is recommended that nonspecific variable designators such as *U* be used sparingly.
- 7) The use of modifying terms "high," "low," "middle" or "intermediate," and "scan" is optional.
- 8) The term "safety" applies to emergency protective primary elements and emergency protective final control elements only. Thus, a self-actuated valve that prevents operation of a fluid system at a higher-than-desired pressure by bleeding fluid from the system is a back-pressure-type *PCV*, even if the valve is not intended to be used normally. However, this valve is designated as a *PSV* if it is intended to protect against emergency conditions, *i.e.*, conditions that are hazardous to personnel and/or equipment and that are not expected to arise normally.

The designation *PSV* applies to all valves intended to protect against emergency pressure conditions regardless of whether the valve construction and mode of operation place them in the category of the safety valve, relief valve, or safety relief valve. A rupture disc is designated *PSE*.

- 9) The passive function *G* applies to instruments or devices that provide an uncalibrated view, such as sight glasses and television monitors.
- 10) "Indicate" normally applies to the readout—analog or digital—of an actual measurement. In the case of a manual loader, it may be used for the dial or setting indication, *i.e.*, for the value of the initiating variable.
- 11) A pilot light that is part of an instrument loop should be designated by a first-letter followed by the succeeding-letter *L*. For example, a pilot light that indicates an expired time period should be tagged *KQL*. If it is desired to tag a pilot light that is not part of an instrument loop, the light is designated in the same way. For example, a running light for an electric motor may be tagged *EL*, assuming voltage to be the appropriate measured variable, or *YL*, assuming the operating status is being monitored. The unclassified variable *X* should be used only for applications which are limited in extent. The designation *XL* should not be used for motor running lights, as these are commonly numerous. It is permissible to use the user's choice letters *M*, *N* or *O* for a motor running light when the meaning is previously defined. If *M* is used, it must be clear that the letter does not stand for the word "motor," but for a monitored state.
- 12) Use of a succeeding-letter *U* for "multifunction" instead of a combination of other functional letters is optional. This nonspecific function designator should be used sparingly.
- 13) A device that connects, disconnects, or transfers one or more circuits may be either a switch, a relay, an ON-OFF controller, or a control valve, depending on the application.

If the device manipulates a fluid process stream and is not a hand-actuated ON-OFF block valve, it is designated as a control valve. It is incorrect to use the succeeding-letters CV for anything other than a self-actuated control valve. For all applications other than fluid process streams, the device is designated as follows:

• A switch, if it is actuated by hand.

• A switch or an ON-OFF controller, if it is automatic and is the first such device in a loop. The term "switch" is generally used if the device is used for alarm, pilot light, selection, interlock, or safety.

• The term "controller" is generally used if the device is used for normal operating control.

• A relay, if it is automatic and is not the first such device in a loop, *i.e.*, it is actuated by a switch or an ON-OFF controller.

- 14) It is expected that the functions associated with the use of succeeding-letter Y will be defined outside a bubble on a diagram when further definition is considered necessary. This definition need not be made when the function is self-evident, as for a solenoid valve in a fluid signal line.
- 15) The modifying terms "high," and "low," and "middle" or "intermediate" correspond to values of the measured variable, not to values of the signal, unless otherwise noted. For example, a high-level alarm derived from a reverse-acting level transmitter signal should be an *LAH*, even though the alarm is actuated when the signal falls to a low value. The terms may be used in combinations as appropriate. (*See* Section 6.9A.)

- 16) The terms "high" and "low," when applied to positions of valves and other open-close devices, are defined as follows: "high" denotes that the valve is in or approaching the fully open position, and "low" denotes that it is in or approaching the fully closed position.
- 17) The word "record" applies to any form of permanent storage of information that permits retrieval by any means.
- 18) For use of the term "transmitter" versus "converter," see the definitions in Section 3.
- 19) First-letter *V*, "vibration or mechanical analysis," is intended to perform the duties in machinery monitoring that the letter *A* performs in more general analyses. Except for vibration, it is expected that the variable of interest will be defined outside the tagging bubble.
- 20) First-letter Y is intended for use when control or monitoring responses are eventdriven as opposed to time- or time schedule-driven. The letter Y, in this position, can also signify presence or state.
- 21) Modifying-letter *K*, in combination with a first-letter such as *L*, *T*, or *W*, signifies a time rate of change of the measured or initiating variable. The variable *WKIC*, for instance, may represent a rate-of-weight-loss controller.
- 22) Succeeding-letter *K* is a user's option for designating a control station, while the succeeding-letter *C* is used for describing automatic or manual controllers. (See Section 3, Definitions.)

Table 1 —	Identification	Letters
-----------	----------------	---------

	FIRST-LE	ETTER (4)	s	UCCEEDING-LETTERS	(3)
	MEASURED OR INITIATING VARIABLE	MODIFIER	READOUT OR PASSIVE FUNCTION	OUTPUT FUNCTION	MODIFIER
А	Analysis (5,19)		Alarm		
В	Burner, Combustion		User's Choice (1)	User's Choice (1)	User's Choice (1)
С	User's Choice (1)			Control (13)	
D	User's Choice (1)	Differential (4)			
E	Voltage		Sensor (Primary Element)		
F	Flow Rate	Ratio (Fraction) (4)			
G	User's Choice (1)		Glass, Viewing Device (9)		
Н	Hand				High (7, 15, 16)
I	Current (Electrical)		Indicate (10)		
J	Power	Scan (7)			
К	Time, Time Schedule	Time Rate of Change (4, 21)		Control Station (22)	
L	Level		Light (11)		Low (7, 15, 16)
М	User's Choice (1)	Momentary (4)			Middle, Intermediate (7,15)
Ν	User's Choice (1)		User's Choice (1)	User's Choice (1)	User's Choice (1)
0	User's Choice (1)		Orifice, Restriction		
Ρ	Pressure, Vacuum		Point (Test) Connection		
Q	Quantity	Integrate, Totalize (4)			
R	Radiation		Record (17)		
S	Speed, Frequency	Safety (8)		Switch (13)	
Т	Temperature			Transmit (18)	
U	Multivariable (6)		Multifunction (12)	Multifunction (12)	Multifunction (12)
V	Vibration, Mechanical Analysis (19)			Valve, Damper, Louver (13)	
W	Weight, Force		Well		
Х	Unclassified (2)	X Axis	Unclassified (2)	Unclassified (2)	Unclassified (2)
Y	Event, State or Presence (20)	Y Axis		Relay, Compute, Convert (13, 14, 18)	
Z	Position, Dimension	Z Axis		Driver, Actuator, Unclassified Final Control Element	

NOTE: Numbers in parentheses refer to specific explanatory notes in Section 5.1.

Internet				Controllers	lers		Readout Devices	Devices	Sv Ala	Switches and Alarm Devices*	nd *se*	Tra	Transmitters								
Antiolity Antiolity <t< th=""><th></th><th></th><th>Decording</th><th>ndireting</th><th>a Ling</th><th></th><th>Decording</th><th>ndireting</th><th>н Ч Сіл **</th><th>-</th><th>4mo U</th><th></th><th>Indicating</th><th>Blind</th><th>Solenoids, Relays, Computing</th><th>Primary Element</th><th></th><th></th><th>Viewing Device,</th><th>Safety</th><th>Final Element</th></t<>			Decording	ndireting	a Ling		Decording	ndireting	н Ч Сіл **	-	4mo U		Indicating	Blind	Solenoids, Relays, Computing	Primary Element			Viewing Device,	Safety	Final Element
CC CC<									NCA					AT				_	01833		
EC FCV, FR F F FSH FSL FSHL FFT FT		Burner/Combuction						2 0					Ηd				Ē		Ca		
FC FC <td< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td>É</td><td>ā</td><td></td><td>DOL</td><td></td><td></td><td></td><td>0</td><td>ā</td><td></td><td></td><td></td><td></td><td></td><td></td></td<>							É	ā		DOL				0	ā						
EC ES ES<		User's Choice																			
FC FC <td< td=""><td></td><td>Voltage</td><td>ERC</td><td>EIC</td><td>С Ш</td><td></td><td>H</td><td>Ξ</td><td>ESH</td><td>ESL</td><td>ESHL</td><td>ERT</td><td>EIT</td><td>ET</td><td>Ę</td><td>Ш</td><td></td><td></td><td></td><td></td><td>EZ</td></td<>		Voltage	ERC	EIC	С Ш		H	Ξ	ESH	ESL	ESHL	ERT	EIT	ET	Ę	Ш					EZ
FIC FOR FOI F		Flow Rate	FRC	FIC	Ð	FCV	FR	Ē	FSH	FSL	FSHL	FRT	FIT	FT	F۲	Ë	£		FG		Ş
FIC FTR F		Flow Ouantity		EOIC			a C a	C	HSCE	EOSI			FOIT	FOT	FOV	ЦСЦ					LO1
HC HC <th< td=""><td></td><td>Flow Ratio</td><td>FFRC</td><td></td><td>C EE</td><td></td><td></td><td></td><td>HCH</td><td></td><td></td><td></td><td>3</td><td>3</td><td>3</td><td>∦ ₩ -</td><td></td><td></td><td></td><td></td><td></td></th<>		Flow Ratio	FFRC		C EE				HCH				3	3	3	∦ ₩ -					
HC KC KCV KR		User's Choice																			
KC KC <td< td=""><td></td><td>Hand</td><td></td><td>HIC</td><td>ЧC</td><td></td><td></td><td></td><td></td><td></td><td>SH</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>-</td></td<>		Hand		HIC	ЧC						SH										-
KC KCV KCV KR J JSH KSH KSH </td <td></td> <td>Current</td> <td>IRC</td> <td><u></u></td> <td></td> <td></td> <td>Щ</td> <td>=</td> <td>ISH</td> <td>ISL</td> <td>ISHL</td> <td>IRT</td> <td>Ħ</td> <td>F</td> <td>≥</td> <td>Ш</td> <td></td> <td></td> <td></td> <td></td> <td>N</td>		Current	IRC	<u></u>			Щ	=	ISH	ISL	ISHL	IRT	Ħ	F	≥	Ш					N
IC ICU IC		Power	JRC	JIC			Яſ	Ę	HSL	JSL	JHSL	JRT	JIT	Ţ	Ł	۳					
LC LCV LR L LSH RSH RSH </td <td></td> <td>Time</td> <td>KRC</td> <td>KIC</td> <td>У Ч</td> <td>KCV</td> <td>ЯX</td> <td>¥</td> <td>KSH</td> <td>KSL</td> <td>KSHL</td> <td>KRT</td> <td>КIТ</td> <td>¥</td> <td>¥</td> <td>КП</td> <td></td> <td></td> <td></td> <td></td> <td>-</td>		Time	KRC	KIC	У Ч	KCV	ЯX	¥	KSH	KSL	KSHL	KRT	КIТ	¥	¥	КП					-
PC PCV PRV PSH PSL PSL <td></td> <td>Level</td> <td>LRC</td> <td>LIC</td> <td>С</td> <td>LCV</td> <td>R</td> <td></td> <td>LSH</td> <td>LSL</td> <td>LSHL</td> <td>LRT</td> <td>LIT</td> <td>Ц</td> <td>Z</td> <td>Е</td> <td></td> <td>LV</td> <td>LG</td> <td></td> <td>_</td>		Level	LRC	LIC	С	LCV	R		LSH	LSL	LSHL	LRT	LIT	Ц	Z	Е		LV	LG		_
PC PCV PR P1 PSH PSL PSHL		User's Choice																			
PC PCV PR P1 PSH PSL PSHL PSL PSHL PSL PSH PSL PS		User's Choice																			
PC PCV PR P1 PSL PSL PSL PSL PSL PSL PSL PSL PSL PPC		User's Choice																			
PDC PDC <td></td> <td>Pressure/ Vacuum</td> <td>PRC</td> <td>PIC</td> <td>РС</td> <td>PCV</td> <td>Я</td> <td>Ē</td> <td>HSH</td> <td>PSL</td> <td>PSHL</td> <td>PRT</td> <td>ЪП</td> <td>РТ</td> <td>Ъ</td> <td>ЫЕ</td> <td>Ч</td> <td></td> <td></td> <td>PSV, PSE</td> <td>Z</td>		Pressure/ Vacuum	PRC	PIC	РС	PCV	Я	Ē	HSH	PSL	PSHL	PRT	ЪП	РТ	Ъ	ЫЕ	Ч			PSV, PSE	Z
Rc Rr CI CSH RSH TH TH <t< td=""><td></td><td>Pressure, Differential</td><td>PDRC</td><td>PDIC</td><td>PDC</td><td>PDCV</td><td>PDR</td><td>IQ</td><td>PDSH</td><td>PDSL</td><td></td><td>PDRT</td><td>PDIT</td><td>PDT</td><td>ΡDΥ</td><td>ЬЕ</td><td>Ч</td><td></td><td></td><td></td><td>PDV</td></t<>		Pressure, Differential	PDRC	PDIC	PDC	PDCV	PDR	IQ	PDSH	PDSL		PDRT	PDIT	PDT	ΡDΥ	ЬЕ	Ч				PDV
RC RR R3H RSH		Quantity	QRC	QIC			QR	ø	QSH	QSL	QSHL	QRT	QIT	ат	۵	QE					QZ
Sc ScV SR S1 SSH SSL SSHL RT SIT ST ST SE Th Th TC		Radiation	RRC	RIC	RC		RR	R	RSH	RSL	RSHL	RRT	RIT	RT	RY	RE		RW			RZ
TC TCV TR T1 TSH T2L TSHL TRT TTT TY TE TP TW TE TP TW TC TDCV TDCV TDR TD1		Speed/Frequency	SRC	SIC	sc	SCV	SR	SI	SSH	SSL	SSHL	SRT	SIT	ST	SΥ	SE					SV
TDC TDCV TDR TDI TDSH TDSI TDSH TDSL TDT TDT TDT TDT TDY TE TP UR UI UR UI VSH VSL VSHL VRT VIT VT VY VE VE WC WCV WDR WDI WDSH WDSL WSHL WRT WIT WT WT WY WE WD7		Temperature	TRC	TIC	10	TCV	TR	F	TSH	TSL	TSHL	TRT	ТІТ	F	Ł	₽	₽	МĻ		TSE	≥
UR UI UI VR VI VSH VSL VSHL VRT VIT VT WC WCV WR WI WSH WSHL WRT WIT WT WDC WDC WDR WDI WSH WSL WSHL WT WT WT YC WDR WDI WDSH WDSL WDRT WDT WDT YC ZC ZCV ZR ZSL ZSHL ZSL ZSHL ZNT ZNT ZDC ZDCV ZDSH ZDSL ZDSL ZDSL ZDSL ZDT ZDT ZD FRK, HIK Control Stations) KOI (Running Time Indicator) ZNT ZDT ZDY TR Accessories) QOI (Running Time Indicator) ZNT ZDY		Temperature, Differential	TDRC	TDIC	TDC	TDCV	TDR	Ī	TDSH	TDSL		TDRT	TDIT	TDT	Ъ	₽	₽	₹			701
WC WC WC W V V V V V V WC WC WC W W W W W V V WD WD WD WD WD WD WD W W V YC WC YR Y Y W W Y YC ZC ZCV ZR ZI ZN ZD Y ZDC ZDV ZDS ZDS ZDS ZDT ZDT ZDT Anter Possible Combinations: FRK, HIK Control Stations) K K K T,R Gatoma Stations) K K Ratio) R		Multivariable					UR	Б							YU						3
WC WCV WR WI WSH WSL WSHL WRT WIT WT WT WT WT WDC WDCV WDR WDI WDSH WDSL WDRT WDIT WDT WDY YC YC YR YI YSH YSL ZSHL ZSHL YT WDT WDY WDY ZC ZCV ZR ZI ZSH ZSL ZSHL ZRT ZIT ZT ZY ZDC ZDCV ZDR ZDI ZDSH ZDSL ZDSL ZDRT ZDIT ZDT ZDY FRK.HIK (Control Stations) KQI (Running Tme Indicator) FRK. HIK (Control Stations) KQI (Running Tme Indicator)		Vibration/Machinery Analysis					X	⋝	NSH	NSL	NSHL	VRT	VIT	5	5	VE					-
WDC WDC/ WDR/WDI WDSH WDSL WDRT WDIT WDT WDY YC YC YR YI YSH YSL ZC ZCV ZR ZI ZSH ZSL ZSHL ZRT ZIT ZT YY ZDC ZDCV ZDR ZDI ZDSH ZDSL ZDRT ZDIT ZDT ZDY FRK, HIK (Control Stations) KQI (Running Tme Indicator) FRK, HIK (Control Stations) KQI (Running Tme Indicator) TIR (Scanning Recorder) WGI (Ratio) HASS Controller)		Weight/Force	WRC	WIC	WC	WCV	WR	M	MSH	MSL	WSHL	WRT	WIT	WT	Ŵ	WE					ZM
YC YR YI YSH YSL YT YT YY ZC ZCV ZR ZI ZSH ZSL ZSHL ZRT ZIT ZT ZY ZDC ZDCV ZDR ZDI ZDSH ZDSL ZDRT ZDIT ZDT ZDY Cther Possible Combinations: FRK, HIK (Control Stations) KCli (Running Time Indicator) FRK, HIK (Control Stations) KCli (Running Time Indicator) TIR (Accessories) QCli (Indicating Control) TIR (Scanning Recorder) WCl (Ratioh-Loss Controller)		Weight/Force, Differential	WDRC	WDIC	WDC	WDCV	WDR	IDM	WDSH	MDSL		WDRT	WDIT	WDT	WDΥ	WE					WDZ
YC YC YR YI YSH YSL YT YT YY ZC ZCV ZR ZI ZSH ZSL ZSHL ZRT ZIT ZT ZY ZDC ZDCV ZDR ZDI ZDSH ZDSL ZDRT ZDIT ZDT ZDY Cher Possible Combinations: FRK, HIK (Control Stations) KCli (Running Time Indicator) FRK, HIK (Control Stations) KCli (Running Time Indicator) TIR (Scanning Recorder) WCl (Running Time Indicator) TIR (Scanning Recorder) WCl (Running Time Indicator)		Unclassified																			
ZC ZV ZR ZI ZSH ZSL ZSH ZIT ZT ZY ZDC ZDCV ZDR ZDI ZDSH ZDSL ZDRT ZDIT ZDY ZDC ZDCV ZDR ZDI ZDSH ZDSL ZDRT ZDT ZDY Cher Possible Combinations: FR (Ratio) FRR (Ratio) FRX HIK (Control Stations) KOI (Running Time Indicator) FIX (Accessories) QOI (Indicating Connet) T.R (Scanning Resource) WOI (Ratio)		Event/State/Presence		YIC	ΥC		ΥR	×	ΥSH	ΥSL				₽	≿	ΥE					Z
ZDC ZDR ZDI ZDSH ZDSL ZDRT ZDIT ZDT ZDY Other Possible Combinations: FO (Restriction Orifice) FFR (Ratio) FRX, HIK (Control Stations) KQI (Running Time Indicator) FX (Accessories) XQI (Indicating Counter) TJR (Scanning Restriction WKIC (Ratio)		Position/Dimension	ZRC	ZIC	ZC	ZCV	ZR	Z	ΖSΗ	ZSL	ZSHL	ZRT	ZIT	ZT	Z	ZE					Ž
Other Possible Combinations: FO (Restriction Orifice) PFR FRK, HIK (Control Stations) KQI FX (Accessories) QQI T.IR (Scanning Recorden) WMC		Gauging/Deviation	ZDRC	ZDIC	ZDC	ZDCV	ZDR	ZDI	HSDZ	ZDSL		ZDRT	ZDIT	ZDT	ZDY	ZDE					ZDV
	: Thi larm, on as	is table is not all-inclusiv , the annunciating devic s S, switch, the actuatin ers H and I, may be omi	/e. .e, may be use g device. itted in the und	d in the sam. efined case	0		Other P FRK, HI	ossible Con (Restric (Contro (Access	hbination stion Orific (Stations) sories)			atio) unning Time idicating Cour	Indicator) nter)								

THE FUNCTION DESIGNATIONS ASSOCIATED WITH CONTROLLERS, COMPUTING DEVICES, CONVERTERS AND RELAYS MAY BE USED INDIVIDUALLY OR IN COMBINATION (ALSO, SEE TABLE 1, NOTE 14.). THE USE OF A BOX AVOIDS CONFUSION BY SETTING OFF THE SYMBOL FROM OTHER MARKINGS ON A DIAGRAM AND PERMITS THE FUNCTION TO BE USED AS A STAND-ALONE BLOCK ON CONCEPTUAL DESIGNS. Table 3 — Function Blocks - Function Designations

GRAPHIC REPRESENTATION DEFINITION	X THE OUTPUT EQUALS THE ALGEBRAIC SUM OF THE INPUTS. THE INPUTS MAY BE LABELED WITH POSITIVE OR NEGATIVE SIGNS).	X X X X X X X X X X X X X X X X X X X	X X X X X X X THE OUTPUT EQUALS THE ALGEBRAIC DIFFERENCE OF THE TWO INPUTS.	THE OUTPUT IS DIRECTLY PROPORTIONAL TO THE INPUT. IN THE CASE OF A VOLUME BOOSTER, "K" MAY BE REPLACED BY 1:1 FOR INTEGER GAINS, 2:1, 3:1. ETC., MAY BE SUBSTITUTED FOR K.	THE OUTPUT VARIES IN ACCORDANCE WITH BOTH THE OUTPUT VARIES IN ACCORDANCE WITH BOTH MAGNITUDE AND DURATION OF THE INPUT. THE OUTPUT IS PROPORTIONAL TO THE TIME INTEGRAL OF THE INPUT.	
BOL MATH EQUATION	M = X ₁ + X ₂ + + X _n	$M = \frac{X_1 + X_2 + \dots + X_n}{n}$	M=X1 - X2	M = KX	$M = \frac{1}{T_1} \int X dt$	
FUNCTION SYMBOI	SUMMING	AVERAGING $\Sigma/_{1}$		PROPORTIONAL 1:1		DERIVATIVE
NO	1 su	2 AV	e HO	4 PRO	2 NT	6 DE

5.4



FUNCTION SYMBOL MATH EQUATION	Ш			H	GRAPHIC REPRESENTATION	RESENTATION	DEFINITION
	X M = X ₁ X ₂	M = X ₁ X ₂		×		×	THE OUTPUT EQUALS THE PRODUCT OF THE TWO INPUTS.
DIVIDING $\mathbf{H} = \frac{X_1}{X_2}$	$\mathbf{+}$ $M = \frac{X_1}{X_2}$	$M = \frac{X_1}{X_2}$	×1 ×2	× 	t x ^x	M t1 t	THE OUTPUT EQUALS THE QUOTIENT OF THE TWO INPUTS.
ROOT EXTRACTION $M = \sqrt{X}$	wW	wW		×		M	THE OUTPUT EQUALS THE ROOT (I.E., CUBE ROOT, FOURTH ROOT, 3/2 ROOT, ETC.) OF THE INPUT. IF n IS OMITTED, A SQUARE ROOT IS ASSUMED.
EXPONENTIAL x^n $M = x^n$	u X = W	u X = W		*			THE OUTPUT EQUALS THE INPUT RAISED TO A POWER (I.E., SECOND, THIRD, FOURTH, ETC.).
NONLINEAR OR UNSPECIFIED FUNCTION M = f(X) M = f(X)	$f(X) \qquad M = f(X)$	$f(X) \qquad M = f(X)$		×		M	THE OUTPUT EQUALS SOME NONLINEAR OR UNSPECIFIED FUNCTION OF THE INPUT.
TIME $M = Xf(t)$ $M = Xf(t)$ $M = f(t)$ $M = f(t)$	f(t) $M = Xf(t)$ $M = f(t)$	M = Xf (t) M = f (t)		× ±1		M t1 t1	THE OUTPUT EQUALS THE INPUT TIMES SOME FUNCTION OF TIME OR EQUALS SOME FUNCTION OF TIME ALONE.
HIGH SELECTING $M = \begin{cases} x_1 FOR \ x_1 \le x_2 \end{cases}$ $x_1 = x_2$	$M = \begin{cases} X_1 FOR \ X_1 \leq X_2 \\ X_2 FOR \ X_1 \leq X_2 \end{cases}$	$M = \begin{cases} X_1 FOR \ X_1 \ge X_2 \\ X_2 FOR \ X_1 \le X_2 \end{cases}$		×	t x1	M 1 1 1 t	THE OUTPUT IS EQUAL TO THE GREATER OF THE INPUTS.

Continued
З
lable
ц
5.4

DEFINITION	THE OUTPUT IS EQUAL TO THE LESSER OF THE INPUTS.	THE OUTPUT EQUALS THE INPUT OR THE HIGH LIMIT VALUE WHICHEVER IS LOWER.	THE OUTPUT EQUALS THE INPUT OR THE LOW LIMIT VALUE WHICHEVER IS HIGHER.	THE OUTPUT IS REVERSELY PROPORTIONAL TO THE INPUT.	THE OUTPUT EQUALS THE INPUT AS LONG AS THE RATE OF CHANGE OF THE INPUT DOES NOT EXCEED A LIMIT VALUE. THE OUTPUT WILL CHANGE AT THE RATE ESTABLISHED BY THIS LIMIT UNTIL THE OUTPUT AGAIN EQUALS THE INPUT.	THE OUTPUT EQUALS THE INPUT PLUS (OR MINUS) SOME ARBITRARY VALUE (BIAS).	THE FORM OF THE OUTPUT SIGNAL IS DIFFERENT FROM THAT OF THE INPUT.
GRAPHIC REPRESENTATION	x x x x x x x x x x x x x x	X X X X X X X X X X X X X X X X X X X			X dX dX dX dX dX dX dX	M M	NONE
. MATH EQUATION	$M = \begin{cases} X_1 FOR \ X_1 \le X_2 \\ X_2 FOR \ X_1 \ge X_2 \end{cases}$	$M = \begin{cases} X FOR X \le H \\ H FOR X \ge H \end{cases}$	M = { X FOR X ≥ L L FOR X ≤ L	M = -KX	$\frac{dM}{dt} = \frac{dX}{dt} \left\{ \begin{array}{l} \frac{dX}{dt} \leq H \text{ AND} \\ M = X \\ M = X \\ \frac{dM}{dt} = H \left\{ \begin{array}{l} \frac{dX}{dt} \geq H \text{ OR} \\ M \neq X \end{array} \right.$	d = X ± b	OUTPUT = f (INPUT)
SYMBOL	V	A	₩	Ϋ́	≯	+ +	*
FUNCTION	LOW SELECTING	HIGH LIMITING	LIMITING	REVERSE PROPORTIONAL	VELOCITY LIMITER	BIAS	CONVERT
Q	4	15	16	17	18	19	20





THE VARIABLES USED IN THE TABLE ARE:

- b ANALOG BIAS VALUE.
- dt DERIVATIVE WITH RESPECT TO TIME.
- H AN ARBITRARY ANALOG HIGH LIMIT VALUE.
- T1 INTEGRATING RATE.
- L AN ARBITRARY ANALOG LOW LIMIT VALUE.
- M ANALOG OUTPUT VARIABLE
- n NUMBER OF ANALOG INPUTS OR VALUE OF EXPONENT.
- t TIME
- T_D derivative time.
- X ANALOG INPUT VARIABLE.
- $X_1, X_2, X_3, \dots, X_n$ ANALOG INPUT VARIABLE (1 TO N IN NUMBER).
- * TABLE 1 LETTER DESIGNATORS.

NOTE: THE SQUARE MAY BE USED AS A FLAG



THIS TABLE HAS BEEN MODIFIED FROM SAMA PMC 22-11-1981 WITH PERMISSION OF THE COPYRIGHT HOLDER, SCIENTIFIC APPARATUS MAKERS ASSOCIATION. COPIES OF PMC 22-11-1981 ARE AVAILABLE FROM ISA, 67 ALEXANDER DR., RESEARCH TRIANGLE PARK, NC 27709; TELEPHONE (919) 549-8411.

6 Drawings

6.1 Cautionary notes

- 1) If a given drawing, or set of drawings, uses graphic symbols that are similar or identical in shape or configuration and that have different meanings because they are taken from different standards, then adequate steps must be taken to avoid misinterpretation of the symbols used. These steps may be to use caution notes, reference notes, comparison charts that illustrate and define the conflicting symbols, or other suitable means. This requirement is especially critical in cases where symbols taken from different disciplines are intermixed and their misinterpretation might cause danger to personnel or damage to equipment.
- 2) The titles *Simplified Diagrams, Conceptual Diagrams* and *Detailed Diagrams* of Section 6.12 were chosen to represent a cross section of symbol usage, not any particular generic document. (*See* 4.4.10 for a more complete discussion.)
- 3) The line symbols of Section 6.2 offer "user's choice" alternative electrical symbols and optional binary symbols. The subsequent examples use one consistent set of these alternatives and apply the binary options. This was done for consistency of appearance of the standard.

It is recommended that the user choose either the dashed line electrical symbol or the triple cross hatch symbol and apply it consistently. The optional binary (on-off) symbols are available for those applications where the user finds it necessary to distinguish between analog and binary signals. If, in the user's judgment, the application does not require such differentiation, the reverse slash may be omitted from on-off signal line symbols. Consistency is recommended on a given set of documents.

6.2 Instrument line symbols

ALL LINES TO BE FINE IN RELATION TO PROCESS PIPING LINES.

(1) INSTRUMENT SUPPLY * OR CONNECTION TO PROCESS UNDEFINED SIGNAL (2) (3) PNEUMATIC SIGNAL ** -++(4) ELECTRIC SIGNAL OR HYDRAULIC SIGNAL (5) CAPILLARY TUBE (6) ELECTROMAGNETIC OR SONIC SIGNAL *** (7)(GUIDED) ELECTROMAGNETIC OR SONIC SIGNAL *** (8) (NOT GUIDED) INTERNAL SYSTEM LINK (9) 0--0-(SOFTWARE OR DATA LINK) -••-(10) MECHANICAL LINK **OPTIONAL BINARY (ON-OFF) SYMBOLS** (11) PNEUMATIC BINARY SIGNAL (12) ELECTRIC BINARY SIGNAL

NOTE: 'OR' means user's choice. Consistency is recommended.

* The following abbreviations are suggested to denote the types of power supply. These designations may also be applied to purge fluid supplies.

AS - Air Supply IA - Instrument Air PA - Plant Air	<pre>Options</pre>
ES - Electric Supply	
GS - Gas Supply	

HS - Hydraulic Supply NS - Nitrogen Supply SS - Steam Supply WS - Water Supply

The supply level may be added to the instrument supply line, e.g., AS-100, a 100-psig air supply; ES-24DC, a 24-volt direct current power supply.

- ** The pneumatic signal symbol applies to a signal using any gas as the signal medium. If a gas other than air is used, the gas may be identified by a note on the signal symbol or otherwise.
- *** Electromagnetic phenomena include heat, radio waves, nuclear radiation, and light.

6.3 General instrument or function symbols

	PRIMARY LOCATION ***NORMALLY ACCESSIBLE TO OPERATOR	FIELD MOUNTED	AUXILIARY LOCATION ***NORMALLY ACCESSIBLE TO OPERATOR
DISCRETE INSTRUMENTS	1 *IP1**	2	3
SHARED DISPLAY, SHARED CONTROL	4	5	6
COMPUTER FUNCTION	7	8	9
PROGRAMMABLE LOGIC CONTROL	10	11	12

- * Symbol size may vary according to the user's needs and the type of document. A suggested square and circle size for large diagrams is shown above. Consistency is recommended.
- ** Abbreviations of the user's choice such as IP1 (Instrument Panel #1), IC2 (Instrument Console #2), CC3 (Computer Console #3), etc., may be used when it is necessary to specify instrument or function location.
- *** Normally inaccessible or behind-the-panel devices or functions may be depicted by using the same symbol but with dashed horizontal bars, i.e.



6.3 General instrument or function symbols (contd.)



* It is not mandatory to show a common housing.

** These diamonds are approximately half the size of the larger ones.

*** For specific logic symbols, see ANSI/ISA Standard S5.2.

6.4 Control valve body symbols, damper symbols



Further information may be added adjacent to the body symbol either by note or code number.

6.5 Actuator symbols



- * Pilot may be positioner, solenoid valve, signal converter, etc.
- ** The positioner need not be shown unless an intermediate device is on its output. The positioner tagging, ZC, need not be used even if the positioner is shown. The positioner symbol, a box drawn on the actuator shaft, is the same for all types of actuators. When the symbol is used, the type of instrument signal, i.e., pneumatic, electric, etc., is drawn as appropriate. If the positioner symbol is used and there is no intermediate device on its output, then the positioner output signal need not be shown.
- *** The arrow represents the path from a common to a fail open port. It does not correspond necessarily to the direction of fluid flow.

6.5 Actuator symbols (contd.)



6.6 Symbols for self-actuated regulators, valves, and other devices





6.6 Symbols for self-actuated regulators, valves, and other devices (contd.)



* The soleniod-tripped pressure relief valve is one of the class of poweractuated relief valves and is grouped with the other types of relief valves even though it is not entirely a self-actuated device.
6.7 Symbols for actuator action in event of actuator power failure (shown typically for diaphragm-actuated control valve).



The failure modes indicated are those commonly defined by the term, "shelf-position." As an alternative to the arrows and bars, the following abbreviations may be employed:

FO - Fail Open

FC - Fail Closed

FL - Fail Locked (last position)

FI - Fail Indeterminate

6.8 Primary element symbols











* Notations such as "mounted at grade" may be added.







* Use of the thermowell symbol is optional. However, use or omission of the symbol should be consistent throughout a project.







 It is expected that control modes will not be designed on a diagram. However, designations may be used outside the controller symbol, if desired, in combinations such as %, f, f.

** A controller is understood to have integral manual set-point adjustment unless means of remote adjustment is indicated. The remote set-point designation is SP.











* See definition of converter versus transmitter.





6.10 Examples — miscellaneous combinations





6.10 Examples — miscellaneous combinations (contd.)



* The purge fluid supplies may use the same abbreviations as the instrument power supplies.

6.10 Examples — miscellaneous combinations (contd.)



6.10 Examples — miscellaneous combinations (contd.)





6.12 Example — degree of detail*





6.12 Example — degree of detail (contd.)*

6.12 Example — degree of detail (contd.)*



Index

Term

Accessible
definition3
graphic symbols6.3
Actuator
actuator action6.7
graphic symbols6.5
identification5.1
Air Supply
identification6.2
Alarm
definition3
examples6.9
identification5.1
Analysis
examples6.8
identification5.1
Assignable
definition3
Auto-Manual Station
(Control Station)
definition3
identification5.1
Auxiliary Location
graphic symbol6.3
Averaging
graphic symbol5.4
- B -
Balloon, Bubble
definition3
graphic symbol6.3
Behind-the-Panel
definition3
graphic symbol 6.3
Bias
graphic symbol5.4

- A -

Term	Para.
Binary	
definition	3
graphic symbol	6.2
Board (Panel)	
definition	3
identification	6.3
Burner, Combustion	
example	6.8
identification	5.1
- C -	
Complex Combinations	
example	6.11
Computer Function	
graphic symbol	6.3
Computing Device	
definition	3
example	6.9
function	5.4
identification	5.1
Conceptual Diagrams	
example	6.12
Conductivity (see Analysis)	
example	6.8
Configurable	
definition	3
Controller	
definition	3
Control	
example	6.9
identification	5.1
Control Station	
(Auto-Manual Station)	
definition	3
example	6.9
identification	5.1
Control Valve	
definition	3

No.

Term	Para. No.
graphic symbols	6.4
identification	.5.1
self-actuated	6.6
Converter	
definition	.3
graphic symbols	5.4
Current (Electrical)	
graphic symbols	
identification	.5.1
- D -	
Damper	
graphic symbol	.6.4
Data Link	
graphic symbol	.6.2
Density	
example	6.8
Derivative	
graphic symbol	5.4
Detailed Diagrams	
example	6.12
Diaphragm Seal	
graphic symbol	6.3
Difference	
graphic symbol	5.4
Differential	
examples	
identification	.5.1
Digital	_
definition	
graphic symbol	6.5
Dimension	
identification	.5.1
Discrete Instruments	~ ~
graphic symbol	6.3
Distributed Control System	•
definition	.3
Dividing	- 4
graphic symbol	.5.4
Driver	~ ~
example	
identification	.5.1
- E -	
Electric Binary Signal	

Term	Para. No.
graphic symbol	6.2
Electric Signal	
graphic symbols	6.2
Electric Supply	
identification	6.2
Electrohydraulic	
graphic symbol	6.5
Electromagnetic Signal	
graphic symbols	6.2
Event	
identification	5.1
Exponential	- /
graphic symbol - F -	5.4
Field Mounted (Local)	
graphic symbol	6.3
Final Control Element	
definition	3
identification	5.1
Flow Rate	
graphic symbols	6.8
identification	5.1
Force	
example	
identification	5.1
Frequency	
identification	5.1
Function	
definition	3
examples	
graphic symbols	
identification	5.1, 5.4
Function Blocks	
identification	5.4
Fusible Plug	
example	6.6
- G -	
Gas Supply	<u> </u>
identification	6.2
Glass (Viewing Device)	e 0
example	
graphic symbols	
identification	5.1

	-	
I	erm	
	-	

Para.	No.
-------	-----

- H -
Hand (Manually Actuated)
example6.9
graphic symbols6.6
identification5.1
Hand Wheel
graphic symbol6.5
High
identification5.1
High Limiting
graphic symbol 5.4
High Selecting
graphic symbol5.4
Hydraulic Signal
graphic symbol6.2
Hydraulic Supply
identification6.2
-1-
Identification
combinations example5.3
definition3
letters 5.1
Indicate
example6.9
identification5.1
Instrument
definition3
Instrument Air
identification6.2
Instrumentation
definition3
Instrument Line Symbols6.2
Integral
graphic symbol5.4
Integrate
example6.9
identification5.1
Interlock
example6.9
graphic symbol6.3
- L -
Letter Combinations5.3

Term	Para. No.
Level	
graphic symbol	6.8, 6.6
identification	5.1
Light	
example	6.9
graphic symbol	6.3
identification	5.1
Local (Field)	
definition	.3
graphic symbol	6.3
Local Panel	
definition	.3
identification	6.3
Loop	
definition	.3
identification	
Louver	
see Damper	
Low	
example	6.9
identification	
Low Limiting	
graphic symbol	54
Low Selecting	
graphic symbol	54
- М -	
Manual Loading Station	
definition	.3
Measurement	•
definition	3
Mechanical Analysis	-
identification	5.1
Mechanical Link	
graphic symbol	62
Middle (Intermediate)	0.2
identification	51
Moisture	0.1
see Analysis	
Momentary	
identification	51
Monitor	0.1
definition	3

Term	Para. N
Multifunction	
example	6.9
identification	5.1
Multiplying	
graphic symbol	5.4
Multivariable	
graphic symbols	6.8
identification	5.1
- N -	
Nitrogen Supply	
identification	6.2
Non-Linear	
graphic symbol	5.4
- 0 -	
Orifice	
identification	5.1
Orifice Plate Taps	
graphic symbols	6.8
- P -	
Panel (Board)	
(Primary Location)	
definition	3
graphic symbols	6.3
Panel-Mounted	
(Board-Mounted)	
definition	3
graphic symbols	6.3
Pilot Light	
definition	3
graphic symbol	6.3
identification	5.1
Plant Air	
identification	6.2
Pneumatic Binary Signal	
graphic symbol	6.2
Pneumatic Signal	
graphic symbol	6.2
Point (Test)	
example	6.9
identification	5.1
Position	
graphic symbol	6.8
identification	5.1

No.	Term Para. No	
	Power	
	graphic symbol6.8	
	identification5.1	
	Presence	
	identification5.1	
	Pressure Relief Valves	
	see Safety Relief Valves	
	Pressure (or Vacuum)	
	graphic symbols6.6, 6.8	
	identification	
	Print	
	example6.9	
	Primary Element (Sensor)	
	definitionsee Sens	or
	graphic symbols6.8	•••
	Process	
	definition	
	Process Variable	
	definition	
	Program	
	definition	
	Programmable Logic	
	Controller	
	definition3	
	example6.10, 6.1	1
	graphic symbol6.3	•
	Proportional	
	graphic symbol	
	Purge	
	example6.10	
	graphic symbol6.3	
	- Q -	
	Quantity	
	examples6.9	
	graphic symbols6.8	
	identification	
	- R -	
	Radiation	
	graphic symbol6.8	
	Ratio	
	example6.9	
	identification5.1	

Term	Para. I
Record	
example	6.9
identification	5.1
Relay	
definition	3
examples	6.9
graphic symbols	5.4
Relief Valve	
see Safety Relief Valve	
Reset	
graphic symbol	6.3
Restriction Orifice	
graphic symbol	6.6
Reverse Proportional	
graphic symbol	5.4
Root Extraction	
graphic symbol	5.4
Rupture Disc	
graphic symbols	6.6
- S -	
Safety	
identification	5.1
Safety Purging	
example	6.10
Safety Relief Valves	
graphic symbols	6.6
Scan	
definition	
example	
identification	.5.1
Self-Actuated Devices	
graphic symbols	
identification	4.2.5
Sensor (Primary Element)	•
definition	
graphic symbols	6.8
Set Point	•
definition	.3
Shared Controller	0
definition	
graphic symbols	6.3
Shared Display	~
definition	3

No.	Term	Para. No.
	graphic symbols	6.3
	Sight Glass	
	graphic symbol	6.6
	Signal Monitor	
	graphic symbol	5.4
	Simplified Diagram	
	example	6.12
	Solenoid	
	graphic symbol	6.5
	Specific Gravity	
	example	6.8
	Speed	
	identification	51
	Steam Supply	
	identification	62
	Straightening Vane	
	graphic symbol	6.6
	Summing	0.0
	•	5 /
	graphic symbol Switch	0.4
		2
	definition	
	example	
	identification	5.1
	- T -	
	Temperature	0.0
	graphic symbols	
	identification	5.1
	Test Point	_
	definition	3
	example	
	identification	5.1
	Time Function	
	graphic symbol	5.4
	Time Rate of Change	
	identification	5.1
	Time, Time Schedule	
	graphic symbols	6.8
	identification	5.1
	Totalize	
	see Integrate	
	Transducer	
	definition	3
	Transmitter	

Term	Para. No.
definition	.3
example	6.9
identification	.5.1
Traps	
example	6.6
Typical Letter	
Combinations	5.3
- U -	
Unclassified	
identification	.5.1
Undefined Signal	
graphic symbols	6.2
User's Choice	
examples	6.8
identification	.5.1
- V -	
Vacuum	
see Pressure	
Valve	
see Control Valve	
Velocity Limiter	
graphic symbol	5.4
Vibration	
identification	.5.1
Voltage	
graphic symbols	.6.8
identification	.5.1
- W -	
Water Supply	
identification	.6.2
Weight	
identification	.5.1
Well	
graphic symbols	
identification	.5.1
- X -	
X-Axis	
identification	.5.1
- Y -	
Y-Axis	
identification	.5.1

- Z-

Z-Axis
identification5.1

Developing and promulgating technically sound consensus standards, recommended practices, and technical reports is one of ISA's primary goals. To achieve this goal the Standards and Practices Department relies on the technical expertise and efforts of volunteer committee members, chairmen, and reviewers.

ISA is an American National Standards Institute (ANSI) accredited organization. ISA administers United States Technical Advisory Groups (USTAGs) and provides secretariat support for International Electrotechnical Commission (IEC) and International Organization for Standardization (ISO) committees that develop process measurement and control standards. To obtain additional information on the Society's standards program, please write:

> ISA Attn: Standards Department 67 Alexander Drive P.O. Box 12277 Research Triangle Park, NC 27709

> > ISBN: 0-87664-844-8